A - 10710"wheel axle position ※ Read instructions thoroughly before M8x60 proceeding. (4) Tighten all parts by hands. Don't use power tool. (3) For your safety, please do not overload. For pneumatic wheel: Please check air pressure in tires. Maintain (30) PSI. (3)Assemble the axle insert 4 spring pins. Please follow \rightarrow direction for assemble. ①nose plate ②axle boxes 3 extension nose plate then tight them. IV III sleeve washer M12x110 5 Insert sleeve washer, wheels in each side, and put the ⑤cotter pins. Please bend the cotter pins. Locking screw